


CAPITAL




HAIR & BEAUTY

Kingsbury Wash Unit




Attention:


Line up all hole and screw before tighten up all the screw.




Step 1.




Step 2.




Step 3.



Step 4.




Step 5.



CAPITAL



HAIR & BEAUTY

Kingsbury Wash Unit





Attention:
Line up all hole and screw before
tighten up all the screw.

Step 1.



Step 2.



CAPITAL

HAIR & BEAUTY

Kingsbury Wash Unit Plumbing Specification

FLOOR FIXING AND WASTE PIPE HOLES




The Wash Unit is fixed to the floor via 2 fixing points in the base moulding.

Option1: The pedestal can be drilled anywhere within the 2 side plumbing access points to allow water & waste pipes to enter / exit the Wash Unit.

Option2: Water & waste pipes to enter / exit the wash unit from the bottom of the pedestal.

Option3: water & waste pipes to enter / exit the wash unit from the back of the pedestal. Use extension cover provided.

Please see Basin Installation Instructions.



CAPITAL

HAIR & BEAUTY

Kingsbury Wash Unit Plumbing Specification

FIXING MULTIPLE WASH UNIT

When fitting more than one wash unit it is recommended there is a 100mm gap between wash unit.

